

## Removing and installing dash panel insert



### Caution

To disconnect and connect the battery, the procedure described in the workshop manual should be strictly adhered to → **Chapter**.



### Note

- ◆ Pull off multi-pin connector and speedometer drive shaft without removing housing.
- ◆ The instruments, warning lamps with plug-in bulb holders and the illumination bulbs can be removed like the voltage stabiliser without removing the housing.
- ◆ The bulbs for the multi-function indicator/digital clock, odometer display and selector lever display, the contact contact plate with speed sender G54 and the multi-function indicator pressure sender can be removed only after removal of the housing.


### Remove steering wheel:


- Unclip cover cap -1-.
- Unscrew hexagon nut -2- (70 Nm).
- Mark steering wheel position and remove steering wheel -3-.

### Remove steering column switch and trim:

- Unscrew cross-head screws -1- and remove trim -2-.
- Pull off connectors at steering column switch -4-.
- Unscrew cross-head screws -5- and pull off steering column switch-4-.
- Remove trim -3-.

### Remove dash panel insert cover:






V70-0559


- Unscrew two panel screws -1- and remove dash panel insert cover -2- from spring clips -3-.

**Remove complete dash panel insert:**



V70-0548

- Unscrew left and right securing bolts -2-.
- Pull out dash panel insert from dash panel and pull off multi-pin connector, multi-function indicator pressure sender hose and speedometer drive shaft on back of dash panel insert.
- Loosen transparent cover securing bolts -1-.
- Unscrew or pull off trip recorder reset button and pull off transparent cover.



# Assembly overview - dash panel insert with rev counter or analogue clock



## Note

- ◆ *Fault finding programmes for specific systems and current circuits:*  
→ *Current flow diagrams, Electrical fault finding and Fitting locations.*
- ◆ *Information on checking voltages, LEDs and bulbs with test box (basic unit) -V.A.G 1598/14- → Chapter.*

### 1 - Transparent cover

### 2 - Rev counter -G5-

- Note different versions
- Removing and installing instruments → Chapter.

### 3 - Speed sender (at dash panel insert) -G54-, mechanical

- Removing and installing instruments → Chapter.
- Removing and installing drive shaft → Chapter.
- Installing speed sender (at dash panel insert) -G54- → Chapter

### 4 - Coolant temperature gauge -G3- and fuel gauge -G1- with cut-out for digital clock -Y2- or 4 A - coolant temperature gauge -G3- and fuel gauge -G1-

- Removing and installing instruments → Chapter.

### 5 - Right turn signal warning lamp - K94-

- Checking LED → Chapter
- Installing → Chapter

### 6 - Right warning lamps

- Installation position → Chapter
- Checking LED → Chapter
- Installing → Chapter

### 7 - Analogue clock -Y-

- Removing and installing instruments → Chapter.

### 8 - Printed circuit board for analogue clock or 8 A printed circuit board with digital clock

- Renewing printed circuit board only in combination with housing
- Components on printed circuit board → Chapter

### 9 - Voltage stabiliser -J6- with cooling panel

- Checking → Chapter
- Removing and installing → Chapter.

### 10 - Housing


- Renewing housing only in combination with printed circuit board

### 11 - Contact plate for speed sender (at dash panel insert) -G54-

- Installing speed sender → Chapter

### 12 - Bulb for digital clock illumination

- Black bulb holder



- 12 V/1.2 W
- Installation position → [Chapter](#)
- Removing and installing → [Chapter](#).

### **13 - Left warning lamps**

- Installation position → [Chapter](#)
- Checking LED → [Chapter](#)
- Installing → [Chapter](#)

### **14 - Left turn signal warning lamp -K65-**

- Checking LED → [Chapter](#)
- Installing → [Chapter](#)

### **15 - Conductor strip for illumination, dash panel insert**

- Printed circuit board connector → [Chapter](#)

### **16 - Bulb for dash panel insert illumination -L10-**

- Blue bulb holder
- 12 V/1.2 W

### **17 - Speed sender (at dash panel insert) -G54-**

- Only with mechanical speedometer
- Installing → [Chapter](#)

# Assembly overview - dash panel insert with multi-function indicator (MFI)



## Note

- ◆ Fault finding programmes for specific systems and current circuits:  
→ [Current flow diagrams](#), [Electrical fault finding](#) and [Fitting locations](#).
- ◆ Information on checking voltages, LEDs and bulbs with test box (basic unit) -V.A.G 1598/14- → [Chapter](#).

### 1 - Transparent cover

### 2 - Rev counter -G5-

- Note different versions
- Removing and installing instruments → [Chapter](#).

### 3 - Speedometer -G21-, electronic

- Removing and installing instruments → [Chapter](#).
- Removing and installing speedometer -G22- → [Chapter](#)

### 4 - Coolant temperature gauge -G3- and fuel gauge -G1- with cut-out for multi-function indicator - J119-

- Removing and installing instruments → [Chapter](#).

### 5 - Right turn signal warning lamp - K94-

- Checking LED → [Chapter](#)
- Installing → [Chapter](#)

### 6 - Right warning lamps

- Installation position → [Chapter](#)
- Checking LED → [Chapter](#)
- Installing → [Chapter](#)

### 7 - Printed circuit board

- Renewing printed circuit board only in combination with housing
- Components on printed circuit board → [Chapter](#), → [Chapter](#)

### 8 - Bulbs for illuminating odometer display, multi-function indicator (MFI) or selector lever display

- Black bulb holder
- 12 V/1.2 W
- Installation position → [Chapter](#)
- Removing and installing → [Chapter](#).

### 9 - Housing


- Renewing only in combination with printed circuit board

### 10 - Pressure sender for multi-function indicator -G55-

- Removing → [Chapter](#).
- Removing dash panel insert beforehand → [Chapter](#)

### 11 - Left warning lamps

- Installation position → [Chapter](#)
- Checking LED → [Chapter](#)



- Installing → [Chapter](#)

## **12 - Left turn signal warning lamp -K65-**

- Checking LED → [Chapter](#)
- Installing → [Chapter](#)

## **13 - Conductor strip for dash panel insert illumination**

- Components on printed circuit board, back → [Chapter](#), → [Chapter](#)

## **14 - Bulb for dash panel insert illumination -L10-**

- Blue bulb holder
- 12 V/1.2 W

## Removing and installing instruments



### Caution


To disconnect and connect the battery, the procedure described in the workshop manual should be strictly adhered to → **Chapter**.



### Note

Before working on components in the dash panel insert, disconnect the battery earth strap.


- 1 - Fuel gauge and coolant temperature gauge
    - additionally with digital clock or multi-function indicator (MFI)
  - 2 - Mechanical speedometer or electronic speedometer - G21-
  - 3 - Analogue clock or rev counter
    - Additionally with selector lever display
- Pull instruments -1 and 3- forwards out of housing; likewise with instrument -2- (electronic speedometer).
- Mechanical speedometer: loosen -2- securing bolts -B- and pull out instrument forwards.






## Installation positions of left warning lamps

- 1 - Coolant temperature/coolant shortage indicator warning lamp (red), LED
- 2 - No connection
- 3 - Oil pressure warning lamp (red), LED
- 4 - Main beam warning lamp (blue), bulb



## Installation positions of right warning lamps

- 1 - Warning lamp (red) for dual circuit brake and handbrake control, LED
  - Seat belt warning system warning lamp (red), LED
- 2 - Alternator warning lamp (red), LED
- 3 - Glow period indicator lamp (yellow), LED
  - Catalytic converter monitoring warning lamp (red), LED
- 4 - No connection




## Installing left/right warning lamps

Replace left and right warning lamps after pulling off top of 4-bulb holder.



### Note


When installing the LEDs make sure polarity corresponds to figure on top of bulb holder.



## Installing left/right turn signal warning lamps (K65/K94)

Insert turn signal warning lamps according to the adjacent figure.

- 1 - LED
- 2 - Top of bulb holder with catch
- 3 - Lower part of bulb holder



## Checking voltage stabiliser -J6-



### Note


Check only if fuel and coolant temperature gauges give false readings. Do not disconnect battery earth strap; multi-pin connector remains plugged into dash panel insert.

### Check voltage supply:

- Remove right instrument.
- Switch on ignition.
- Voltmeter between terminal 15 -a- and earth -b-.  
Specification: approx. battery voltage
- If the specification is not attained, check wiring according to current flow diagram.

### Check output voltage:

- Voltmeter between output 15 -c- and earth -b-. Specification: 9.5...10.5 V
- If the specification is not attained, voltage stabiliser is defective; renew.




## Removing and installing voltage stabiliser -J6- (mechanical speedometer)

- Remove right indicator instrument
- Unscrew securing bolt -2- and remove voltage stabiliser -1- from contacts -a, b, c- downwards.



### Note


*When installing make sure that the 3 connections are inserted in the contacts -a-, -b-, -c- and that the stabiliser is firmly screwed onto the cooling panel -3- (heat dissipation from the housing).*



## Removing and installing speedometer sender - G22-


The speedometer sender -G22- is bolted to the gearbox instead of the speedometer drive shaft and supplies 4 pulses per revolution.

- After pulling off connector, loosen sender using suitable wrench, 22 mm, and unscrew by hand.



## Components on printed circuit board front on vehicles with digital clock -Y2-


- 1 - Printed circuit board
- 2 - Conductor strip for dash panel insert illumination
- 3 - Connector for conductor strip
- 4 - Left/right turn signal warning lamps
- 5 - Recess for voltage stabiliser bolted on a cooling plate with the dash panel insert housing
- 6 - Right warning lamps
- 7 - Left warning lamps
- 8 - Digital clock, do not renew separately






## Components on printed circuit board back on vehicles with digital clock -Y2-

- 1 - Printed circuit board
- 2 - Oil pressure warning buzzer, do not renew separately
- 3 - Conductor strip for dash panel insert illumination
- 4 - Connector for conductor strip
- 5 - 28-pin connector for dash panel insert wiring harness
- 6 - Digital clock illumination
- 7 - Warning lamp bulb holder




## Installation positions of bulbs for illuminating odometer display, multi-function indicator (MFI)/digital clock and selector lever display

- 1 - Bulb for selector lever display illumination
- 2 - Bulb for odometer display illumination
- 3 - Bulb for MFI / digital clock illumination




## Removing and installing bulbs for illuminating odometer display, multi-function indicator (MFI)/digital clock and selector lever display

- Turn bulb holder until notch -1- is vertical (unlocked) and pull out bulb.
- Insert new bulb and turn bulb holder until notch -1- is horizontal (locked).




## Components on printed circuit board front on vehicles with MFI

- 1 - Printed circuit board
- 2 - Conductor strip for dash panel insert illumination
- 3 - Left/right turn signal warning lamps
- 4 - Right warning lamps
- 5 - Odometer display, do not renew separately
- 6 - Left warning lamps
- 7 - Multi-function indicator (MFI), do not renew separately




## Components on printed circuit board back on vehicles with MFI

- 1 - Voltage stabiliser, do not renew separately
- 2 - Oil pressure warning buzzer
- 3 - Conductor strip for dash panel insert illumination
- 4 - Connector for conductor strip
- 5 - 28-pin connector for dash panel insert wiring harness



## Removing and installing multi-function display pressure sender -G55-

- Loosen cross-head bolts -3-.
- Pull pressure sender off dash panel insert.




## Removing speedometer drive shaft from dash panel



### Note

The drive shaft is split in the engine compartment and locked on the dash panel insert.

- Release plastic coupling of drive shaft at dash panel insert by compressing the side web and pull off drive shaft from housing.
- Unscrew coupling -1- from drive shaft and pull out drive shaft with rubber gasket -2- through opening in partition to passenger compartment.




## Checking LED

The negative terminal is marked by:


- 1 - Phase on diode housing
- 2 - Larger terminal in diode housing

With some diodes the negative terminal connection is also offset.



- At hand multimeter -V.A.G 1526 B- simultaneously press buttons for resistance and voltage measurement -arrows-.
- Connect red terminal "+" to LED (+).
- Connect black terminal "-" to LED (-).

LED must light up.





## Installing speed sender (at dash panel insert) -G54-



### Caution


To disconnect and connect the battery, the procedure described in the workshop manual should be strictly adhered to → **Chapter**.




### Note

Speed sender signals are required for speed-dependent systems in the vehicle. On vehicles with mechanical speedometer the sender is bolted onto back of the instrument and supplies 7 pulses per wheel revolution. Inductive senders (2-pin) or Hall sender (3-pin) are used for radio with Gala 1994 ►.


- Carefully break out part -A- at perforated separating line on back of dash panel insert.




- Insert speed sender in the recess created -1- and screw firmly with cross-head bolts -3-.



- Make sure that conductor strip -3- lies without folds on sender spring contact.




- Secure contact plate -A- with bolts -B-.




## Checking voltages, LEDs and bulbs with test box (basic unit) -V.A.G 1598/14-

### Special tools and workshop equipment required

- ◆ Test box with 9 adapters -V.A.G 1598/A-
- ◆ Adapter cable -V.A.G 1598/13-



- ◆ Voltage tester -V.A.G 1527 B-



- ◆ Hand multimeter -V.A.G 1526 B-

#### Note

- ◆ The bush markings on the test box (basic unit) -V.A.G 1598/14- are identical with the contact markings on the dash panel insert.
- ◆ If the specification is attained, check conductor strip with connectors and components.
- ◆ In case of deviation from specification, check wiring harness according to current flow diagram. → [Current flow diagrams](#), [Electrical fault finding and Fitting locations](#)

#### Note

Replace the dash panel wiring harness if it is found to be defective when the line positions are checked. The dash panel wiring harness must not be repaired.

#### Test prerequisites:

- ◆ Battery voltage OK.
- ◆ Affected fuses OK. → [Current flow diagrams](#), [Electrical fault finding and Fitting locations](#)

1 - Dash panel insert



2 - Test box (basic unit) -V.A.G 1598/14- with connecting cable -3-


4 - Hand multimeter -V.A.G 1526 B-

5 - Adapter line -V.A.G 1598/8-

6 - Dash panel insert wiring harness

- Fold down cover in front of relay plate.
- Disconnect multi-pin connector behind dash panel insert -1-.
- Connect test box (basic unit) -V.A.G 1598/14- with adapter line -V.A.G 1598/13- to dash panel insert and disconnected wiring harness (plug must audibly engage).

**Test table:**



**- Measuring range: Switch on voltage measurement -V-.**

Test step	Bushes - V.A.G 1598-	The voltage supply is tested	<ul style="list-style-type: none"> <li>• Test conditions</li> <li>- Additional operations</li> </ul>	Specifications
1	11 + 3	Terminal 30/terminal 31	<ul style="list-style-type: none"> <li>• Ignition switched off</li> </ul>	Approx. battery voltage
2	13 + 3	Terminal 15/terminal 31	<ul style="list-style-type: none"> <li>- Switch on ignition.</li> </ul>	Approx. battery voltage
3 → Note	22 + 3	Left turn signal warning lamp	<ul style="list-style-type: none"> <li>• Ignition switched on</li> <li>- Connect test lamp.</li> <li>- Switch on left turn signal.</li> </ul>	Test lamp flashes
4 → Note	24 + 3	Right turn signal warning lamp	<ul style="list-style-type: none"> <li>• Ignition switched on</li> <li>- Connect test lamp.</li> <li>- Switch on right turn signal.</li> </ul>	Test lamp flashes
5	12 + 3	Illumination for dash panel insert and digital display	<ul style="list-style-type: none"> <li>• Ignition switched on</li> <li>- Switch on light switch.</li> </ul>	Approx. 2.5 V to battery voltage, depending on position of controller E 20
6	25 + 3	Main beam warning lamp	<ul style="list-style-type: none"> <li>• Ignition switched on</li> <li>- Switch on high beam.</li> </ul>	Approx. battery voltage
7	18 + 3	Dual circuit and handbrake system warning lamp	<ul style="list-style-type: none"> <li>• Ignition switched on</li> <li>- Apply handbrake.</li> <li>- Release handbrake.</li> </ul>	Approx. battery voltage approx. 0 V approx. battery voltage
8	16 + 3	Alternator warning lamp	<ul style="list-style-type: none"> <li>• Ignition switched on</li> </ul>	Approx. 0 V

			– Start engine.	approx. battery voltage
9 → Note	13 + 20	Glow period indicator lamp	<ul style="list-style-type: none"> <li>• Engine cold (below glow temperature)</li> <li>– Switch on ignition.</li> </ul>	Approx. battery voltage until glow temperature is attained

1) Use test lamp -V.A.G 1527-

2) Not possible with hot engine

## Pin assignment of connections on dash panel insert

### 28-pin connector

- 1 - Ambient temperature sensor, earth → **Note**
- 2 - to coolant shortage indicator sender
- 3 - Terminal 31, earth
- 4 - MFI save switch (reset) → **Note**
- 5 - Terminal 31, earth → **Note**
- 6 - MFI save switch (memory) → **Note**
- 7 - Signal from speedometer at dash panel insert -G54- or from electronic speedometer -G21-
- 8 - Oil pressure switch 0.9 bar / 1.4 bar / 1.8 bar
- 9 - Oil pressure switch 0.3 bar
- 10 - Terminal 1 / terminal W or speed signal from Digifant engine control unit
- 11 - Terminal 30, battery positive
- 12 - Terminal 58b, illumination
- 13 - Terminal 15
- 14 - Rear fog light
- 15 - MFI call-up button (mode) → **Note**
- 16 - Alternator warning lamp, terminal 61

1) Only with multi-function indicator

- 17 - Oil temperature sender <sup>1)</sup>
- 18 - Dual circuit and handbrake system warning lamp / seat belt warning system warning lamp
- 19 - Ambient temperature sensor, signal<sup>1)</sup>
- 20 - Glow period warning lamp
- 21 - Fuel gauge
- 22 - Left turn signal warning lamp
- 23 - Coolant temperature gauge
- 24 - Right turn signal warning lamp
- 25 - Main beam warning lamp
- 26 - Consumption signal from Digifant control unit, as of 01.93<sup>1)</sup>
- 27 - Speed signal from speedometer sender (G 22)
- 28 - Selector lever display, as of 08.92

Only with multi-function indicator

